

## Technical bulletin

---

## TB-061

### Important Installation Instruction

When fitting a power steering rack with identical mounting bushes, use the vehicles original bolts.

If replacing Power Steering Rack

... with rubber mounting bushes



... with metal mounting bushes



please use the attached bolts.  
Size M12 X 64