

Technical bulletin

TB-079

Important Notification

This starter is insulated.
You must connect B-cable to the B-Terminal.

